

ACECO

FC6001MK **RF TRACER**

Introduction

The Aceco FC6001MK radio frequency tracer is useful in locating stuck transmitters or bugging devices in a room or automobile. It excels at tracing RF signals for RF security and counter-surveillance applications. Supplied as a complete with internal NiCd pack, AC wall charger and short rubber antenna.

Specifications

Frequency range:	1 MHz - 6 GHz
Weight:	230 g
Size:	100 mm high x 68 mm wide x 31 mm deep
Impedance:	50 Ohms (BNC Socket)
Case:	Stamped aluminum with black anodized finish
Battery:	Internal 5 x AA 600 mAh NiCd pack
Power:	9 VDC 300 mA

Features

- Pocket size
- Built-in speaker to output alert tone
- 5 section RSSI bargraph to show relative RF signal strength
- Low power consumption (Average 8 hour battery life)
- Supplied with NiCd pack, AC wall charger and short rubber antenna

Controls

SEN Knob - This knob turns the tracer on and adjusts sensitivity.

Battery

This tracer can operate for up to eight hours from its fully charged NiCd batteries. They are charged when the unit is plugged into the supplied AC/DC adapter. Full recharge will occur over 12 to 16 hours. Before recharging the batteries you should be deep cycled occasionally by allowing them to completely discharge to maintain maximum battery capacity. The NiCd batteries should last for several years. However, it is a good idea to check them every twelve months for signs of corrosion or leakage. Always replace the whole set if any one cell fails.

Warranty

Aceco Electronics, Corp. guarantees the tracer and accessories for one year against defects in manufacture. This warranty does not cover items that have been modified, subject to unauthorized repairs, misuse or abuse. This warranty does not cover damage caused by excessive power levels 15 dBm applied to the signal input.

CAUTION

Never make any kind of connection between the unit and a transmitter.